

be withdrawn from the jet, thus allowing more fuel to flow. Similarly, as the air-flow falls, due to reduced engine requirements, so the piston falls. In this way, a state of balance is maintained whereby the piston keeps at a certain height, dependent on the engine speed and the throttle opening. Thus the carburetter automatically adjusts itself to the varying requirements of the engine under all conditions.

Hand Starting Control.

The jet is so mounted that it is vertically adjustable by hand from the steering wheel.

For starting, the jet is lowered away from the needle by setting the mixture control to "**Start**". This provides an enriched mixture to ensure easy starting and even running when the engine is cold. As soon as the engine has warmed up, the control lever should gradually be re-set to "**Run**".

Adjustment of Carburetters.

There should be no necessity for any variation of the adjustment of the carburetters as fixed by the makers.

It is realised, however, that information as to the methods for restoring adjustments may prove valuable under special circumstances, and is consequently given, as far as practicable, in the paragraphs which follow.

Automatic Air Valve.

The automatic air valve is of the conventional S.U. pattern, and includes a hydraulic suction piston damper to delay the rise of the air valve piston during acceleration and when starting the engine from cold. The damper consists of a small cylindrical brass plunger (2, Fig. 14), attached by a thin steel rod to the oil cap nut (4, Fig. 13). Inside the plunger is a one-way ball valve which seats in an upward direction. The plunger is a free fit in the hollow guide rod of the automatic air valve piston, the chamber being filled with a thin oil. The action of the device is as follows:—

When the automatic air valve piston rises in accordance with the demands of the engine, the movement is retarded due to the displacement of oil through the clearance existing between the damper plunger and the guide rod. The fall of the automatic air valve is unimpeded due to the ball valve being opened, which allows the unrestricted passage of the displaced oil. No attention should be necessary other than the replenishment of the oil in the reservoir.

Every month, as directed on page 30, the oil reservoir cap nut (4) (Fig. 13), should be unscrewed and the plunger withdrawn, *great care being taken to avoid damage to the plunger rod by bending*; the reservoir should be topped up, if required, with the recommended oil, so as to maintain the level of the oil to the top of the guide rod only. The




Fig. 14.—CARBURETTER—EXPLODED VIEW.

- | | |
|-----------------------------|----------------------------------|
| 1. Air valve cylinder. | 9. Nut (not to be disturbed). |
| 2. Hydraulic damper piston. | 10. Plug securing float chamber. |
| 3. Suction disc. | 11. Throttle valve. |
| 4. Piston, air valve. | 12. Gauze strainer. |
| 5. Needle valve. | 13. Float depressing plunger. |
| 6. Grub screw. | 14. Throttle stop. |
| 7. Mixture lever. | 15. Piston guide rod. |
| 8. Adjustable stop. | 16. Jaw, jet head. |

plunger should then be replaced, taking care that no dirt or grit is present. A slight steady pressure may be required to displace the oil sufficiently to allow the engagement of the thread of the oil reservoir cap nut.

If it is suspected that the automatic air valve is not working correctly, the air intake (10, Fig. 13), should be removed, and a check made by lifting the piston with the fingers, when it should be noted that the piston falls quite freely on to its seat when released.

If any sticking or sluggishness is apparent, it will be necessary to dismantle the air valve assembly; first remove the hydraulic piston damper, next remove the three screws (5, Fig. 13), and lift off the cylinder (3). The piston valve can be then lifted out, *the utmost*

care being taken not to bend or damage its depending needle valve (5, Fig. 14), or to bruise the valve in any way. The valve, cylinder and guide, should be carefully wiped with a piece of clean cloth dipped in petrol, and the piston rod ONLY lubricated with a few drops of thin oil.

No polishing paste or abrasives should be used to clean the valve or cylinder.

The suction disc (3, Fig. 14), does not touch the walls of the cylinder, there being a small clearance, and it is centralised solely by the piston rod working in the guide. Therefore, any sluggishness in movement is probably due to dirt in the guide, or on the cylinder walls.

When replacing the valve, it will be noticed that there is a slot which must engage a tongue provided on the carburetter body. The cylinder can only be replaced in one position, the three screw holes being unevenly spaced to ensure this.

If the above treatment does not effect a cure, the fault may be due to a bent jet needle or alternatively to the needle fouling the jet. If this is suspected it is recommended that communication is made with Messrs. Bentley Motors (1931) Ltd., or one of their "Special Retailers".

The needle valve is secured in position by means of a grub screw, (6, Fig. 14), and if it should be necessary to remove this, as, for instance, when replacing an accidentally damaged needle, it must be particularly noticed that the location of the valve is determined by a shoulder. The valve should be pushed into the piston until this shoulder is just flush with the lower face and the grub screw tightened.

If a needle should be accidentally damaged, a new one must be obtained from either Messrs. Bentley Motors (1931) Ltd., or one of their "Special Retailers". A number is stamped on the end of the needle, denoting the size, and it is essential that only one of the same number is refitted.

Throttle Control.

The quantity of mixture for slow running is determined by means of an adjustable screw stop on the front carburetter (7, Fig. 13), which limits the closing movement of both throttles. This is so adjusted that the engine will idle slowly but reliably when the hand throttle lever on the steering wheel is set right to the bottom of its range and the accelerator pedal released. The stop on the rear carburetter is normally inoperative, and is only used to help initial adjustment.

Re-adjustment of the jets, and of the control shaft between the carburetters, should not normally be required. If, however, the whole adjustment has been disturbed, first adjust the throttles so that both carburetters function equally at "fast idle". An indication that both pistons have risen can be felt by depressing the top of the piston guide rod (15, Fig. 14) by means of a small rod inserted through the top of the cylinder (3, Fig. 13), after removal of the oil cap nut and hydraulic piston damper (4, Fig. 13). The jets should then be adjusted subsequent to this operation, as described below.

Mixture Control and Slow Running.

The mixture control lever on the steering wheel operates to raise or lower the actual fuel orifice or jet, through the medium of the levers (6, Fig. 13.). Raising the jet causes the taper needle to sink further into the orifice, so weakening the mixture. Conversely, lowering the jet enriches the mixture. This control is only intended to provide a means of strengthening the mixture for starting from cold, for normal running the jets must be in their highest position, the back of both the jaws (16, Fig. 14), abutting against the adjustable stops (8, Fig. 14), simultaneously.

The strength or quality of the mixture for slow running is set by means of these adjustable stops, the procedure being as follows:—

With the engine warm, the control rods should be disconnected from the ends of the levers (6, Fig. 13), and the latter pushed up until the jaws (16, Fig. 14), are against the stops (8, Fig. 14). Then, with the engine running, the stops should be manipulated until the engine runs regularly. Any sign of "hunting" is due to the mixture being too rich, and one or both of the stops must be screwed farther in and the lever pushed up so that the jaw is against it.

On the other hand, irregular firing, indicated by irregular pulsations from the exhaust pipe, shows the mixture to be weak, and one or both stops must be screwed out a little.

The correct positions for the stops having been found, the control rods must be adjusted so that the jaws of both jets are definitely against the stops when the lever on the steering wheel is at "Run".

Float Feed Mechanisms.

These are of the usual "top feed" pattern, whereby, as the level of the petrol rises in the float chamber, a lever bearing on the top of the float moves the conical seat "needle" upwards on to its seating, so shutting off the supply.

If it is required to dismantle the float chambers, it will be most convenient to remove them bodily—after removing the fuel pipes—by unscrewing the hexagon plugs (10, Fig. 14), which secure each to its carburetter body.

When the covers are removed, care must be taken that the fulcrum pins of the levers do not fall out. They are normally retained by means of the walls of the float chambers.

The chambers should be wiped out with a piece of clean wash-leather before being refitted. When replacing them, care must be taken to see that the packing washers are in position, one above and one below the boss which couples each to the carburetter body.

Further Dismantling of Carburetter.

It should never be necessary to remove any other parts of the carburetters than those referred to in the foregoing pages.

The large hexagon (9, Fig. 14), should not be disturbed, as the refitting of this requires special tools to ensure that the jet is accurately centralised relative to the taper needle valve.

Air Cleaner and Silencer.

A cleaner is provided within the front end of the air silencer to prevent the passage of dust and grit to the engine.

The cleaner comprises a composite steel-wool element through which the air passes on its way to the carburetter. It is removed by unscrewing the wing nut in the centre of the end cover and removing the cover; the element may then be withdrawn.

Every 10,000 miles, unless the car is being operated under particularly dusty conditions, when the cleaning must be carried out at 5,000 miles' intervals or even less, depending upon the dust concentration, the cleaner element should be removed and carefully washed in petrol or paraffin, and afterwards oiled with engine oil. It should be thoroughly drained before re-fitting.

Warning.

On no account should the engine be kept running for any appreciable period with the car in a closed garage. There is a grave danger of people in the garage being asphyxiated, owing to the presence of poisonous gases in the exhaust.

Consequently, particular care should be taken always to open the garage doors wide before starting the engine.




Fig. 15.—DIAGRAM OF BENTLEY BRAKING SYSTEM.

CHAPTER VI

The Braking System

General Description—Possible Variations—Adjustments—Adjustment of Hand Brake—Adjustment of Servo—Lubrication—Bleeding the Hydraulic System—Hydraulic Master Cylinder.

General Description.

The Bentley four-wheel braking system is of the Servo assisted type, and comprises a mechanically driven servo motor of the dry disc-brake type, which is equally effective for either forward or backward movement of the car. Further, even should the servo be out of action, the rod operated rear brakes are still directly coupled to the pedal.

Pressure on the pedal applies the rear brakes direct in the usual manner, and also engages the servo, but the front brakes which are of the hydraulically operated type are actuated entirely by the servo acting through the medium of a balance lever and hydraulic master cylinder.

The servo effect is distributed between the front and rear brakes, being added therefore to the direct pedal effect in the case of the rear brakes. With the leverages provided, this results in about 55 per cent. of the total braking being imposed on the front wheels, which allows for the fact that greater weight is thrown upon the front wheels during braking.

The proportioning of the servo pull to the front and rear brakes respectively is effected by a balancing lever. A separate equaliser is provided for the two rear brakes, which, with the hydraulic operation of the front brakes, ensures even braking on either side of the car.

The hand brake lever operates the rear brakes only and uses the same linkage as the foot pedal.

A diagrammatic representation of the whole system is shown in Fig. 15.

A pull rod (1, Fig. 15), operated by the pedal, is coupled to a lever (2), on the servo motor shaft, the motor itself (3) being mounted on the off-side of the gearbox, and driven at approximately one-tenth of the propeller shaft speed.

The lever (2) has inclined cams formed on the face of its boss, these cams engaging, through the medium of steel balls, similar cams formed on the boss of another lever (4). From the latter a rod (5) directly actuates the rear brakes through the medium of the levers (6) and (7), which are pivoted on a bracket bolted to the "X" member of the frame, and finally, through the rear equaliser (8) mounted on a bracket suspended from the axle.

The output from the servo is taken by one of the two rods (9), according to whether the car is moving forwards or backwards, to the lever (10). This lever carries, in turn, a balance lever (11), the lower end of which is connected by the rod (12) to the rear brake lever (7), thus augmenting the direct pedal effort, while its upper end is coupled to the master cylinder (13), which actuates the front brakes.

The dashboard hand brake (14), is mounted under the fascia board, convenient to the driver's right hand. The ratchet release is so arranged that should it be inadvertently knocked or pressed, the brakes will not be released. In order to release the brakes, the trigger must be fully depressed and held in this position. The hand brake is then pulled, as if applying the brakes, and this action frees the ratchet permitting the brakes to be released, provided that the trigger is still held. This device is particularly useful in preventing accidental release of the brakes when the car is parked.

To obtain this action, the trigger is not directly connected to the ratchet pawl, but compresses a spring. This spring, in turn, operates the pawl, but is only strong enough to move it out of engagement when the load has been removed by pulling on the hand brake.

The hand brake is connected by an enclosed cable (15), to a horizontal lever (16), mounted on the "X" section of the frame which provides the required leverage, and is in turn coupled to the rear brakes, through the levers (7) and (17) and the rear equaliser. The same rear brake-shoes are used, therefore, as for the pedal operation, and the application and release of the hand brake can be lightened accordingly by simultaneous application of the foot brake.

Possible Variations.

As already mentioned, the leverages are so proportioned that the total braking effort is distributed in a predetermined ratio between the front and rear brakes.

This distribution will be upset if the servo brakes are allowed to become badly out of adjustment, or if the servo, for any reason, fails to give its correct output. A less likely cause would be oil or grease on the brake linings.

The need for adjustment of the rear brakes will be indicated by excessive travel of the hand brake lever, whereas the front brakes, which are operated by the servo motor only, will not affect the hand brake or pedal travel.

It is unlikely, however, that the front brakes will wear more rapidly than the rear brakes, so, provided that they are adjusted whenever adjustment of the rear brakes is required, no trouble in this respect need be expected.

Low or inconsistent output from the servo would be indicated by heavy or non-progressive brake pedal action, together with insufficient front braking, in which case the servo would have to be dismantled to ascertain the cause of the trouble. As this is a delicate operation, it is recommended that Messrs. Bentley Motors (1931) Ltd., or one of their "Special Retailers" be entrusted with this work.

A light pedal action, accompanied by defective front braking, resulting in the rear wheels locking, would indicate a fault in the front braking system. An excess of front braking would indicate a fault in the rear brakes.

In the unlikely event of oil reaching either of the rear brakes, the self-seal bearing on the rear axle half shaft will be at fault. Grease catchers are provided for the front hubs, and provided that the recommended grease be used and the quantity limited to $1\frac{1}{2}$ ozs. in each hub, this should not be able to reach the brake linings.

Adjustments.

A separate adjustment is provided on each brake carrier plate to compensate for wear of the brake shoe linings, and is the only adjustment provided on the whole system.

It is important to note that in no circumstances should adjustments be attempted at any other point, for instance, by altering the lengths of the brake rods. These are all carefully determined during erection of the chassis, with a view to synchronisation of the front and rear safety stops, which ensure that in the event of failure of any part of the system, at least one pair of brakes will remain available.

The method of adjustment is the same for both front and rear brakes, with the exception that a hand wheel is provided on the rear brake adjusters, while a $\frac{1}{4}$ " B.S.F. open-ended spanner must be used on the squared end of the front brake adjusters. The rear adjusters (2, Fig. 17) are located forward of the axle tubes, and the front adjusters (1, Fig. 16) directly below the steering pivot pins.

For each complete turn of the adjusters, four "clicks" will be felt, and between each "click" the brake shoes are expanded towards the drum, approximately $.014$ ", and then moved back $.010$ ", giving an incremental adjustment of $.004$ ", and a running clearance of $.010$ ".

To adjust the brakes, rotate the adjusters in a clockwise direction until considerable resistance is felt. This resistance must be equal for all four brakes, and should the last "click" on any one adjuster require noticeably greater force to obtain, the adjuster should be turned back to the previous "click". This will give the correct brake adjustment.

It is not necessary to jack up the car to adjust the brakes, as the adjusters are so designed to give the correct shoe clearances automatically.

If, after long service, the brake linings require renewal, this will be apparent by the adjusters coming to the end of their travel, and will have a solid feel quite distinct from the resistance felt when the brake shoes are correctly adjusted.




Fig. 16.—FRONT BRAKE ADJUSTMENT.

1. Adjuster screw.
2. Hydraulic pipe.
3. Bleeder connection.




Fig. 17.—REAR BRAKE ADJUSTMENT.

1. Brake drum.
2. Adjuster screw.

Adjustment of Hand Brake.

Adjustment of the rear brakes takes up both the pedal and hand brake clearance in the same operation. No other adjustment is required.

Adjustment of the Servo.

The servo is of the dry disc-brake type, and is shown in Fig. 15. An adjustment is provided for the initial setting and wear of the friction surfaces, but once correctly set, should require no further attention for a considerable period, as very little wear occurs. As the operation is of a delicate nature it is advised that this adjustment should be effected by Messrs. Bentley Motors (1931) Ltd., or one of their "Special Retailers".

Lubrication.

The need for hand lubrication of various parts of the mechanism has been reduced to a minimum, by the use of self-lubricating bearing bushes at the fulcrum of practically all levers.

The only points that require attention are the jaws and pins of the pull rods and intermediate levers (6, 7 and 17, Fig. 15). Oil should be applied to these points every 5,000 miles, as directed on page 31. The ball bearing cams which actuate the servo (as described earlier in this chapter) are filled with lubricant upon initial build, and require no attention between overhauls of the chassis.




Fig. 18.—THE HYDRAULIC MASTER CYLINDER AND RESERVOIR.

- | | |
|-----------------------------------|---------------------|
| 1. Filler Plug. | 3. Pin. |
| 2. Master Cylinder and Reservoir. | 4. Support Bracket. |

Bleeding the Hydraulic System.

Bleeding, that is to say expelling air from the system, should only be necessary when completely recharging the system with fluid following the removal of a component or the disconnection of a pipe joint. Under normal conditions air does not enter the system as a result of brake application.

To bleed the system, proceed as follows:—

1. Attach a clean rubber drain tube to one front brake bleeder screw (3, Fig. 16), and immerse the other end in a clean glass jar in which there is sufficient hydraulic brake fluid to submerge the end of the tube.

2. Release the bleeder screw (3) half to one turn.
3. Remove the filler plug (1, Fig. 18) and fill the reservoir integral with the master cylinder, with the recommended fluid. (See page 28.)
4. Push the joint forward until the extended pin (3) abuts against the master cylinder support brackets (4).
5. Release, pause slightly, and repeat until the reservoir is nearly empty, but taking care not to empty it completely.
6. Tighten the bleeder screw and transfer drain tube to the other front brake.
7. Refill the reservoir and bleed this brake in a similar manner.
8. Finally, refill the reservoir and replace the filler plug.

Hydraulic Master Cylinder.

The fluid level in the master cylinder should be examined every 10,000 miles, as directed on page 33, and topped up if necessary so as to maintain the level at one inch below the filler cap.

A rapid fall in the fluid level indicates a leak at some point in the system, and must be traced and rectified.