

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASS'LY NOTES

GROUP P4A Continued

LEVER, butterfly operating, complete with ball joints

9 RE.17020 1

LEVER, solenoid shaft

10 RE.21686 1

L

NUT, full, 3BA, diaphragm rod

X21 K.4005/Z 1

NUT, full, 2BA, cover plate and Otter switch

K.4006/Z 4

NUT, half, 2BA, adjusting screw

X24 K.4307/Z 1

NUT, half, 2BA, butterfly valve shaft

X24 K.4307/Z 1

NUT, half, 2BA, solenoid stud

K.4307/Z 2

NUT, insulated, Otter switch

11 DB.440 2

L

PLATE, doubling

12 UE.2648 1

PLATE, cover

13 RE.13200 1

PIN, butterfly valve shaft

RE.13208 1

ROD, diaphragm to butterfly link

14 RE.17003 1

SCREW, Otter switch

X50 K.2804/Z 2

SCREW, adjusting diaphragm

15 RE.13199 1

SCREW, C/sk head, bifurcated, butterfly valve

16 UE.2808 3

SCREW, cheese head, 5BA, diaphragm cover

X44 K.1710/Z 4

SCREW, 3BA, spring tensioner

X53 KC.102/Z 1

L

SHAFT, butterfly valve assembly, complete with lever RE.13207 and link assembly depression valve RE.13204

RE.22941 1

K

SHAFT, butterfly valve assembly, with link assembly depression valve RE.13204

17 UE.2806 1

L

SOLENOID, carburetter starting assembly including

RD.6501 1

K

Clip, cover

RD.6499 1

Cover

RD.6500 1

Screw, terminal

RD.6495 1

SOLENOID, carburetter starting assembly

18 RD.8574 1

L

SPRING, diaphragm

19 RE.16621 1

SPRING, Automatic choke

20 RE.21682 1

L

STOP, butterfly valve

21 RE.13198 1

TENSIONER, spring, solenoid lever

22 RE.21683 1

L

P15/7/56.

PRINTED IN ENGLAND

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY GROUP ASS'Y NOTES

GROUP P4A Continued

VALVE, butterfly	23	RE.19870	1	
WASHER, adjusting rod				B
.015" thick - RE.17040	24			
.020" thick - RE.17041				
.025" thick - RE.17042				
SWITCH, oil pressure, choke solenoid	25	RE.21917	1	L
SWITCH, Otter, Bi-metal	26	UD.1819	1	L
WASHER, aluminium, pipe junction	X83	KB.1078	1	
WASHER, plain, .200" dia., butterfly valve shaft	X85	K.4404/Z	1	
WASHER, shim, solenoid				B
.009" thick - RD.6516	27			
.012" thick - RD.6517				
.015" thick - RD.6518				
WASHER, spring, 5BA, diaphragm cover	X87	K.9003/Z	4	
WASHER, spring, 2BA, butterfly valve shaft		K.9006/Z	1	
WASHER, spring, 2BA, cover plate		K.9006/Z	2	
WASHER, spring, .250"., butterfly valve stop		K.9008/Z	1	
WASHER, Thackeray, Otter switch	X90	K.3803	2	L

GROUP P5

PEDAL ACCELERATOR (RC)
(SYNCHROMESH GEARBOX TO CHASSIS NO.B-434-TN)

Comprising:-

BOLT, 2BA, pedal	X9	K.131/Z	2	
BOLT, .250" dia., front pedal bracket to frame	X10	K.206/Z	1	
BOLT, .250" dia., rear pedal bracket to frame	X10	K.305/Z	1	
BRACKET, lever bearing	1	FB.4486	1	
CAP, anti-fume seal	2	FB.473	1	
HOLDER, pedal upward stop	3	FB.4455	1	
LEVER, accelerator pedal, assembly with 2 off bush FB.3587	4	FB.3791	1	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSEMBLY NOTES

GROUP P5 Continued

NUT, castellated .375" dia., spindle to bracket	X20	KB.3585/Z	1	
NUT, half, 3 BA, anti fume seal screw	X24	K.4304/N	2	
NUT, half, 2BA, pedal holder to lever bolt	X24	K.4307/Z	2	
NUT, half, .250" dia., pedal bracket to frame bolt	X.24	K.4310/Z	2	
PEDAL, accelerator assembly	5	RF.4293	1	
PIECE, distance, anti-fume seal screw	6	F.61510	2	
PIN, split, .093" dia., spindle to bracket nut	X31	K.4608/Z	1	
RETAINER, anti-fume seal	7	F.61548	1	
SCREW, cheese head 3BA, anti-fume seal	X45	K.1816/N	2	
SPINDLE, lever bearing	8	FB.3792	1	
SPRING, anti-fume seal	9	F.60920	1	
SPRING, pedal lever return	10	FB.3790	1	
STOP, pedal, downward, additional	11	FB.3777		B
STOP, pedal, downward, short	12	FB.3776	1	
STOP, pedal, upward	13	FB.4458	1	
WASHER, felt, anti-fume seal	14	F.60930	1	
WASHER, plain, felt retaining screw	X85	K.4446/Z	2	
WASHER, spring, 3BA, seal screw	X87	K.9005/Z	2	
WASHER, spring, 2 BA, pedal bolt	X87	K.9006/Z	2	
WASHER, spring, .250" dia., bracket bolt	X87	K.9008/Z	2	
WASHER, thrust, lever bearing	15	FB. 3795	1	

GROUP P5A

PEDAL, ACCELERATOR (RC)

(SYNCHROMESH GEARBOX FROM CHASSIS NO. B-436-TN & ON)

(AUTOMATIC GEARBOX ALL CHASSIS)

Comprising :-

BOLT, 2BA, pedal, clamping	X9	K.132/Z	2	
BOLT, 2BA, pivot pedal	X9	K.120/Z	1	
BOLT, .250" dia., bracket to frame	X10	K.241/Z	3	
BRACKET, pedal to frame	1	RF.9426	1	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY GROUP ASSEMBLY NOTES

GROUP P5A Continued

CAP, anti-fume seal	2	FB.473	1	
HOLDER, pedal upward stop		FB.4455	1	✱
LEVER, accelerator pedal assembly, consisting of:	3	RF.9420	1	
Boss		RF.9424	1	
Bush, oilite		RF.9423	2	
Lever, accelerator pedal		RF.9421	1	
Lever, throttle operating		RF.9422	1	
LINK, spring, pedal return	4	RG.5050	2	
NUT, half, 3BA, anti-fume seal	X24	K.4304/Z	2	
NUT, half, 2BA, pedal holder to lever bolt		K.4307/Z	2	
NUT, half, 2BA, pivot bolt		K.4307/Z	1	
NUT, half, .250" dia., pedal bracket to frame bolt		K.4310/Z	3	
PEDAL, accelerator assembly	5	RF.4293	1	
PIECE, distance, anti-fume seal screw	6	F.61510	2	
PIECE, distance, accelerator pedal	7	RF.9425	1	
PIECE, clamping, accelerator pedal	8	RF.9427	1	
PLATE, backing, gas tight joint		RF.6165	1	✱
RETAINER, anti-fume seal	9	F.61548	1	
SCREW, cheese head, 3BA, anti-fume seal	X45	K.1816/N	2	
SPRING, anti-fume seal	10	F.60920	1	
SPRING, pedal lever return	11	GB.5097	1	
STOP, pedal, downward, additional	12	FB.3777		B
STOP, pedal, downward, short	13	FB.3776	1	
STOP, pedal, upward		FB.4458	1	✱
WASHER, felt, anti-fume seal	14	F.60930	1	Q
WASHER, plain, felt retaining screw	X85	K.4446/Z	2	
WASHER, spring, 3BA, seal screw	X87	K.9005/Z	2	
WASHER, spring, 2BA, pedal bolt	X87	K.9006/Z	2	
WASHER, spring, 2BA, pivot, accelerator	X87	K.9006/Z	1	
WASHER, spring, .250" dia., bracket bolt	X87	K.9008/Z	3	

NOTE: ✱ Used on cars fitted with synchromesh gearbox.

Q Used on cars fitted with automatic gearbox.

P18/7/56.

PRINTED IN ENGLAND

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASS'LY NOTES

GROUP P5B

PEDAL ACCELERATOR (LC)
(SYNCHROMESH GEARBOX)

Comprising:-

BOLT, 2BA, pedal stop	X9	K.132/Z	1	
BRACKET, pedal off stop	1	RF.7048	1	
LINK, pedal spring	2	RG.5050	2	
NUT, half, 2BA, off stop, accelerator		K.4307/Z	1	
PEDAL, accelerator assembly	3	RF.8186	1	
PIECE, distance, pedal off stop	4	RF.7050	1	
SCREW, cheese head, 2BA, bracket	X54	KC.171/Z	2	
SPRING, pedal lever return	5	GB.5097	1	
STOP, pedal off	6	RF.7049	1	
WASHER, plain, pedal stop, chamfered	X84	KB.3904/Z	1	
WASHER, plain, pedal stop	X85	K.4452/Z	1	
WASHER, spring, 2BA, off stop		K.9006/Z	1	

GROUP P5C

PEDAL ACCELERATOR (LC)
(AUTOMATIC GEARBOX)

Comprising:-

LINK, pedal spring		RG.5050	1	Q
LINK, pedal spring	1	RG.3446	1	+
PEDAL, accelerator assembly		RF.8578	1	Q
PEDAL, accelerator assembly	2	RF.9801	1	+
SCREW, cheese head, 2BA, pedal bracket	X54	KC.171/Z	2	
SPRING, pedal lever return	3	GB.5097	1	
WASHER, spring, 2BA, pedal bracket	X87	K.9006/Z	2	

NOTE: Q Used on cars fitted with cast-iron
bell housing (up to B-33-JL)+ Used on cars fitted with aluminium
bell housing (B-35-UG on)

P19/7/56.

PRINTED IN ENGLAND

SCHEDULE OF SPARE PARTS

REF. NO. PART NO.

QUANTITY
GROUP ASSEMBLY

NOTES

GROUP P6

PIPES

Comprising :-

BOLT, 2BA, drain pipe, clip, front carburetter	X9	K.101/Z	1
BOLT, 3BA, breather pipe clip	X8	K.3602/Z	1
BOLT, 2BA, pipe clip	X9	K.102/Z	5
BOLT, 2BA, pipe clip to frame	X9	K.130/Z	1
BOLT, .250" dia., breather pipe junction	X10	K.206/Z	3
BRACKET, petrol drain pipe clip, front carburetter	1	RE.12279	1
BUSH, rubber, .312" dia., pipe	2	FW.1465	3
BUSH, rubber, .375" dia.	3	FW.1466	3
BUSH, threaded, 2-way junction	4	RF.6780	7
CLIP, drain pipe, front carburetter	5	RF.3549	1
CLIP, insulated, .312" dia., pipe	6	RF.3336	3
CLIP, insulated, .375" dia., pipe	7	RF.3332	3
CLIP, tank breather extension pipe	8	RF.3549	1
JUNCTION, 2-way, tank breather pipe on 2nd crossmember	9	RF.6784	2
JUNCTION, 2-way, tank breather pipe on side member	10	RF.6785	1
NUT, half, 3BA, tank breather pipe clip	X24	K.4304/Z	1
NUT, half, 2BA, pipe clip retaining bolt	X24	K.4307/Z	6
NUT, half, 2BA, drain pipe clip, front carburetter	X24	K.4307/Z	1
NUT, half, .250" dia., junction retaining bolt	X24	K.4310/Z	3
NUT, half, .562" dia., adaptor	X24	KB.5085/Z	2
NUT, tubing, Enot's .312" dia., pipe	X25	KB.3023	1
NUT, tubing, Enot's .375" dia., pipe	X25	KB.3024	4
PIPE, drain, front carburetter, assembly	11	RE.12277	1
PIPE, fuel feed to carburetter assembly (LC)		RE.17623	1
PIPE, fuel feed to carburetter assembly (RC)	12	RE.20572	1
PIPE, filter to pump	13	RF.7201	1
PIPE, flexible, frame to engine (LC)	14	RF.6489	1
PIPE, flexible, frame to engine (RC)	15	RF.8054	1
PIPE, overflow, rear carburetter assembly with banjo EW.1249	16	RE.5352 A	1
PIPE, pump to frame bracket for flexible pipe with adaptor RE.3526	17	RF.5064	1
PIPE, petrol tank breather, crossmember	18	RF.8209	1
PIPE, tank breather, extension		RF.6389	1

P20/7/56.

PRINTED IN ENGLAND

SCHEDULE OF SPARE PARTS

REF. NO. PART NO.

QUANTITY
GROUP ASS'LY

NOTES

GROUP P6 Continued

PIPE, tank breather, frame junction to filler	19	RF.9231	1	
PIPE, tank breather, frame to crossmember	20	RF.5067	1	
PIPE, tank breather, junction to atmosphere	21	RF.8887	1	
PIPE, tank to filter (Coachbuilt body)		RF.7202	1	
PIPE, tank to filter (Standard body)	22	RF.9261	1	
SLEEVE, compression, .312" dia., pipe	X59	KB.3003	1	
SLEEVE, compression, .375" dia., pipe	X59	KB.3004	4	
SLEEVE, compression, tank breather pipe	23	RF.6783	7	
UNION, outlet	X80A	KB.3044	1	
WASHER, aluminium, .625" dia.	X83	KB.1081	1	
WASHER, spring, 3BA, breather pipe clip	X87	K.9005/Z	1	
WASHER, spring, 2BA, pipe clip bolt	X87	K.9006/Z	6	
WASHER, spring, 2BA, drain pipe clip bolt, front carburettor	X87	K.9006/Z	1	
WASHER, spring, .250" dia., junction bolt	X87	K.9008/Z	3	
WASHER, spring, .562" dia., feed pipe adaptor	X87	K.9013/Z	1	
WASHER, spring, .562" dia., bracket adaptor	X87	K.9013/Z	1	

GROUP P7

PUMP

Comprising :-

BLOCK, mounting (nearest frame) assembly consisting of:	1	RD.4006	1	
Block, rubber		RD.4006		1
Plate, mounting		DB.1931		1
BLOCK, mounting (nearest pump) assembly consisting of:	2	RD.4007	1	
Block, rubber		RD.4007		1
Plate, mounting		DB.1931		1
BOLT, .250" dia., bracket to frame, retaining	X10	K.241/Z	4	
BOLT, square head, terminal		RD.8072	2	
BRACKET, supporting, pump to frame	3	RD.4008	1	
CABLE, earth assembly	4	RD.5392	1	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO.

QUANTITY
GROUP ASS'LY

NOTES

GROUP P7 Continued

COVER, rubber

5 DW.554 2

DIAPHRAGM, neoprene assembly, consisting of:

6 RD.6881 2

Armature

1789A 1

Diaphragm

1783 1

Plate, brass

1790D 1

Spindle

1669 1

Washer, impact .010" thick

HOUSING, coil and contact assembly, consisting of:

7 DB.194.2 2

Blade, support

1809 1

Bush, Tufnol, core guide

1788 1

Coil

1457 1

Contact

1458 1

Contact

1677 1

Cover, end

1677 1

Housing, H.P.

1677 1

Piece, bridge

1677 1

Screw, terminal

1677 1

Spring, toggle

1677 1

NUT, half, .250" dia., bracket bolt

X24 K.4310/Z 4

NUT, half, .312" dia., pump to bracket

X24 K.4313/Z 2

NUT, terminal, 2BA, assembly consisting of:

8 DB.440A 2

Cover

DB.440 1

Insert, screwed

DB.439 1

PIECE, distance, mounting blocks

9 RD.4005 2

PLUG, filter

RD.7509 2

PUMP, electric, fuel, assembled complete

RD.6903 1

UNION, inlet

RD.7510 1

UNION, outlet

RD.7511 1

SCREW, cheese head, pump body

RD.7512 10

WASHER, aluminium, .625" dia., fuel inlet and outlet unions

X83 KB.1081 2

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSY

NOTES

GROUP P7 Continued

WASHER, fibre, SV1442	10	RD.6232	2	
WASHER, plain, 2BA, terminal	X85	K.4405/N	2	
WASHER, spring, 2BA, terminal	X90	K.3803/N	2	
WASHER, spring, .250" dia., bracket to frame retaining bolt	X87	K.9008/Z	4	
WASHER, spring, .312" dia., pump to bracket	X87	K.9009/Z	2	

GROUP P8

SILENCER, AIR INTAKE

Comprising :-

BRACKET, return spring assembly, with pin RE.19937	1	RE.17046	1	
BRACKET, support, silencer	2	RE.11537	2	
BUSH, air intake, (with synchromesh gearbox)	3	RE.3470	1	
CLIP, jubilee, silencer to auto. choke body	4	RE.4805	2	
COLLAR, return spring	5	RE.3525	1	
CONNECTION, rubber, silencer to auto. choke body	6	RE.17017	1	
INTAKE, air assembly with	7	RE.17031	1	
Intake		RE.13237	1	
Stud, 2BA, return spring bracket		KB.299/Z	1	
Stud, .250" dia., auto. choke body		KB.351/Z	4	
Stud, .250" dia., bellcrank lever		KB.357/Z	1	
JOINT, air intake to auto. choke body	8	RE.13241	1	
JOINT, air intake to carburettor	9	RE.10620	2	
LINK, return spring		E.51877	1	
NUT, full, 2BA, return spring bracket	X21	K.4006/Z	1	
NUT, half, .250" dia., auto. choke body stud	X24	K.4310/Z	4	
NUT, full, .250" dia., bellcrank lever stud (with synchromesh gearbox)	X21	K.4008/Z	1	
PIECE, distance, pivot (automatic gearbox)	10	RE.18355	1	

P23/7/56.

PRINTED IN ENGLAND

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY GROUP ASSEMBLY NOTES

GROUP P8 Continued

PIN, split, .031" dia., return spring collar	X31	K.4646/Z	1	
PIVOT, throttle levers (automatic gearbox 301-on)	11	RE.18359	1	
SCREW, set, .250" dia, bracket to silencer	X55	KC.201/Z	4	
SCREW, set, .312" dia., intake to carburettor	X55	KC.297/Z	4	
SCREW, set, 2BA, throttle levers retaining (automatic gearbox 301-on)	X54	KC.152/Z	1	
SILENCER,		RE.11529	1	K
SILENCER,	12	RE.21771	1	L
SPRING, return, throttle		RE.17032	1	
WASHER, plain, .250" dia., bellcrank lever stud (synchromesh gearbox)	X85	K.4407/Z	1	
WASHER, plain, throttle lever, retaining (automatic gearbox)	X85	K.4405/Z	1	
WASHER, spring, 2BA, return spring bracket	X87	K.9006/Z	1	
WASHER, spring, 2BA, throttle levers retaining		K.9006/Z	1	+
WASHER, spring, .250" dia., auto. choke body (4) support bracket (4)	X87	K.9008/Z	8	
WASHER, spring, .250" dia., bellcrank lever (with synchromesh gearbox)	X87	K.9008/Z	1	
WASHER, spring, .250" dia., pivot throttle lever		K.9008/Z	1	+
WASHER, spring, .312" dia., carburettor flange	X87	K.9009/Z	4	

NOTE: + Used on cars fitted with aluminium bell housing (All RC and B-35-UL on LC)

GROUP P8A SILENCER, AIR INTAKE - AIR CLEANER (SPECIAL PARTS ONLY)

Comprising :-

BOLT, 2BA, elbow to adaptor	X9	K.131/Z	8	
BOLT, .250" dia., plate and strap	X10	KA.202/Z	4	
BRACKET, steady, oil bath	1	RE.7448	1	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSY LY NOTES

GROUP P8A Continued

CLEANER, air, assembly, including

2 RE.21992 1

Filter

E/AC2913-4 1

Screw, retaining, with knob

RE.13650 1

Washer, cork

RE.17409 1

CLIP, jubilee, oil bath to elbow

3 RE.6732 1

CLIP, jubilee, banjo connection to silencer

4 RE.4805 1

CONNECTION, banjo, assembly

5 RE.13657 1

ELBOW, support, oil bath air cleaner

6 RE.6278 1

NUT, half, 2BA, elbow to adaptor

X24 K.4307/Z 8

NUT, half, .250" dia., support plate (2)

X24 K.4310/Z 4

oil bath to steady bracket (2)

PLATE, support

7 RE.6269 1

RING, rubber, banjo connection to silencer

8 RE.4804 1

RING, rubber, oil bath to elbow

9 RE.6271 1

SCREW, set, .250" dia., bracket to silencer

X55 KC.201/Z 2

SCREW, set, .250" dia., strap to oil bath

X55 KC.201/Z 3

SILENCER, air, assembly

10 RE.11562 1

STRAP, support, oil bath

11 RE.6275 1

SUPPORT, oil bath air cleaner

12 RE.6276 2

WASHER, joint, support plate

13 RE.6270 2

WASHER, spring, 2BA, elbow to adaptor

X87 K.9006/Z 8

WASHER, spring, .250" dia., bracket support

X87 K.9008/Z 2

WASHER, spring, .250" dia., support strap

X87 K.9008/Z 3

to oil bath

WASHER, spring, .250" dia., support strap

X87 K.9008/Z 2

oil bath, to steady bracket

GROUP P9

TANK, FUEL

Comprising :-

BALL, steel, .125" dia., locating filler cap
bolt

1 RF.6907 1

SCHEDULE OF SPARE PARTS

REF NO. PART NO.

QUANTITY
GROUP ASSEMBLY

NOTES

GROUP P9 Continued

BOLT, petrol cap locking	2	RF.9205	1	
BOLT, .250" dia., seal washer retaining	3	RF.9207	1	
BOLT, .250" dia., strap supporting	4	FW.503	2	
CLIP, hose	6	RE.6739	2	
CAP, petrol filler	5	RF.9201	1	
FILLER, tank assembly, consisting of :	7	RF.9219	1	
Adaptor, breather pipe		RF.9212	1	
Cable		RF.4262	1	
Head		RF.9200	1	
Lug, cable retaining		RF.9211	1	
Nipple, cable retaining		RF.4263	2	
Nut, cap		RF.9208	1	
Rivet, retaining lug		KB.1806	2	
Tube, filler		RF.9218	1	
GAUGE, electric level	8	RF.9227	1	
GUARD, gauge unit	9	RF.9237	1	
GUARD, tank	10	RF.9240	1	
HOSE, rubber, filler tube to tank connection	11	RF.8985	1	
HOUSING, bolt, petrol cap locking	12	RF.9204	1	
LOCK, petrol cap, assembly, consisting of:	13	RF.9214	1	
Cam		RF.9206	1	
Lock		RF.9213	1	
Nut, lock	13	RF.9352	1	
Screw, countersunk head		RF.9215	1	
NUT, castellated .250" dia., strap supporting bolt	X20	KB.3581/Z	2	
NUT, half, .250" dia., strap tension stud	X24	K.4310/Z	4	
PACKING, fabric, support strap	14	RF.8841	1	
PIECE, distance, petrol filler cap	15	RF.9202	3	
PIN, split, .062" dia., x .750" long strap support bolt	X31	K.4602/Z	2	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO.

QUANTITY
GROUP ASSY LV

NOTES

GROUP P9 Continued

PIN, split, .062" dia., x 1.000" long sleeve support	X31	K.4603/Z	4	
PLATE, bolt stop, petrol filler cap	16	RF.9203	1	
PLUG, tank, drain	17	RF.7860	1	
SCREW, cheese head, 3BA, gauge unit retaining	X45	K.1804/Z	6	
SCREW, countersunk head, 3BA, petrol filler lock	X49	K.2719/Z	3	
SCREW, set, 2BA, tank guard	X54	KC.151/Z	4	
SCREW, petrol filler lock	18	RF.9291	1	
SLEEVE, strap support	19	RF.8843	2	
SPRING, petrol filler lock	20	RF.9290	1	
STRAP, tank support assembly	21	RF.8833	2	
TANK, fuel assembly	22	RF.9232	1	
WASHER, aluminium, 1.000" dia., tank drain plug	X83	KB.1084	1	
WASHER, plain, 2BA, tank guard	X85	K.4404/Z	4	
WASHER, plain, .250" dia., strap supporting bolt	X85	K.4407/Z	2	
WASHER, retaining, petrol filler cap	23	RF.9210	1	
WASHER, sealing, petrol filler cap	24	RF.9209	1	
WASHER, spring, 3BA, gauge unit screw	X87	K.9005/Z	6	
WASHER, spring, 2BA, tank guard	X87	K.9006/Z	4	
WASHER, gauge unit	25	RF.8404	1	

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY GROUP ASSY. NOTES

SECTION P.

Bentley Continental 'R' Type
As for Bentley 'R' Type except:

GROUP P.2.

	Continental	Qty	Standard	Qty
BRACKET, LH, countershaft to dashboard with bush RE.10110	RE. 9930	1	RE.11257	1
BRACKET, RH, countershaft to dashboard with bush RE.10110	RE. 9929	1	RE.11258	1
COUNTERSHAFT, dashboard	RE.10109	1	RE.18537	1

The following parts are additional:-

BODY, ball joint	E. 70594	4
BOLT, 2 BA, hand throttle lever	K. 133/Z	1
BOLT, countersunk head, ball joint locking	RE. 3520	4
BRACKET, steering column countershaft with 2 off bush RE.3535	RE.3551A	1
COUNTERSHAFT, throttle assembly (steering) consisting of:-	RE. 4275	1
* Bolt, 3 BA, lever to shaft	K.3620/Z	1
* Lever, bracket to steering	EW. 797	1
Lever, bracket to carburettor	EB. 4877	1
* Nut, 3 BA, lever to shaft bolt	K.4304/Z	1
Pin, ball joint	RE. 3257	2
Pin, taper, .093" dia.	K. 4852	1
Plug, shaft	EB. 5078	1
Shaft	EB. 5176	1
* Washer, 3 BA, lever to shaft	K.9005/Z	1
LEVER, throttle countershaft assembly, with	RE.5267A	1
Bush	RE. 4668	1
Pin ball	RE.3527	1
LEVER, hand throttle assembly steering column	RE. 9668	1
NUT, 2 BA, control rods	K.4307/Z	4
NUT, ball joint body locking bolt	RE. 3667	4
ROD, control, bracket to dashboard	RE. 5276	1
ROD, control, column to bracket	RE. 5274	1
SCREW, adjusting ball joint body	E.70595	4

CP1/12/55.

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSY. NOTESSECTION P (Continued)GROUP P.2.A.

The following parts are additional:-

BOLT, 2 BA, hand throttle lever	K.133/Z	1
BOLT, 3 BA, housing, spherical bearing	K.3601/Z	4
BEARING, spherical, hand throttle shaft	RE.7739	2
BRACKET, upper, hand throttle control	RF.9874	1
COLLAR, .1875" dia., shaft, hand throttle control	KB.1178/Z	1
HOUSING, spherical bearing	RE.7740	4
LEVER, hand throttle, steering column assy	RE.9668	1
LINK, assembly, hand throttle control	RE.7734	1
NUT, 2 BA, hand throttle lever	K.4307/Z	1
NUT, 3 BA, spherical bearing housing bolts	K.4304/Z	4
PIN, plain, .187" dia., link hand throttle	KB.4507/Z	2
PIN, split, .062" dia., link hand throttle control	K.4601/Z	2
PIN, split, .062" dia., shaft, hand throttle control	K.4602/Z	1
SCREW, set, 2 BA, bracket, upper hand throttle	KC.152/Z	2
SHAFT, assembly, hand throttle control	RE.18486	1
WASHER, plain, .200" dia., bracket, upper hand throttle control	K.4404/Z	2
WASHER, spring, 2 BA, bracket, upper hand throttle control	K.9006/Z	2
WASHER, spring, 2 BA, lever, hand throttle control	K.9006/Z	1
WASHER, spring, 3 BA, spherical bearing housing	K.9005/Z	4

GROUP P.5.A.Continental Qty Standard Qty

LEVER, accelerator assembly	RF.9877	1	RF.9420	1
-----------------------------	---------	---	---------	---

For use when steering column is swung out $1\frac{1}{2}$ " from parallel to centre line of car (with automatic gearbox)

GROUP P.6.D Series Onwards.

PIPE, fuel feed to carburettors with connections (LC)	RE.21510
PIPE, fuel feed to carburettors with connections (RC)	RE.21506

CP2/12/55.

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSY LY NOTESSECTION P (Continued)GROUP P.9.BALL, steel, .125" dia., locating filler cap
bolt

RF.6907 1

BOLT, fuel cap locking

RF.9205 1

BOLT, .250" dia., seal washer retaining

RF.9207 1

BOLT, .250" dia., strap support

FW. 503 6

CAP, fuel filler

RF.9201 1

CLIP, hose, filler

RE.6739 2

CONNECTION, flexible filler

FB.2447 2 =

FILLER, tank assembly, consisting of

RF.9023 1 =

Adaptor

RF.9212 1

Cable

RF.4262 1

Head

RF.9200 1

Lug, cable retaining

RF.9211 1

Nipple, cable

RF.4263 2

Nut, cap

RF.9208 1

Rivet, retaining nut

KB.1806 2

Tube, filler

RF.9022 1

FILLER, tank assembly, as above except

RF.9219 1 *

Tube, filler

RF.9218 1

GAUGE, electric, fuel level

RF.5410 1 =

GAUGE, electric, fuel level

RF.9227 1 *

GUARD, stone, gauge unit

RF.3485 1 =

GUARD, stone, gauge unit

RF.9237 1 *

GUARD, stone, fuel tank

RF.9240 1 *

HOSE, filler tube to tank connection

RF.8176 1 =

HOSE, filler tube to tank connection

RF.8985 1 *

HOUSING, bolt, filler cap locking

RF.9204 1

LOCK, fuel cap assembly, consisting of:-

RF.9214 1

Cam

RF.9206 1

Lock

RF.9213 1

Nut, lock

RF.9352 1

Screw, countersunk head

RF.9215 1

NUT, castellated, .250" dia., strap supporting
bolt

KB.3581/Z 6 =

NUT, castellated, .250" dia., strap supporting
bolt

KB.3581/Z 2 *

NUT, half, .250" dia., shoe front support

K.4310/Z 4 =

NUT, half, .250" dia., seal retaining bolt

K.4310/Z 1 =

NUT, half, .250" dia., strap tension stud

K.4310/Z 4 *

CP3/12/55.

SCHEDULE OF SPARE PARTS

REF. NO. PART NO. QUANTITY
GROUP ASSY

NOTES

SECTION P (Continued)

GROUP P.9. (Continued)

PACKING, fabric, support strap	RF.3993	2	=
PACKING, fabric, support strap	RF.8841	1	*
PIECE, distance, fuel filler cap	RF.9202	3	
PIN, split, .062" dia., x .750" strap support bolt	K.4602/Z	6	=
PIN, split, .062" dia., x .750" strap support bolt	K.4602/Z	2	*
PIN, split, .062" dia., x 1.000", sleeve support	K.4603/Z	4	
PLATE, bolt, stop, fuel filler cap	RF.9203	1	
PLUG, tank drain	RG.3744	1	=
PLUG, tank drain	RF.7860	1	*
SCREW, cheesehead, 3 BA, gauge unit retaining	K.1804/Z	6	
SCREW, countersunk head, 3 BA, fuel filler lock	K.2719/Z	3	
SCREW, set, 2 BA, tank guard	KC.151/Z	4	*
SCREW, fuel filler lock	RF.9291	1	
SHOE, strap support front	RF.3078	2	=
SLEEVE, strap support front	RF.9791	2	=
SLEEVE, strap support	RF.8843	2	*
SPRING, fuel filler lock	RF.9290	1	
STRAP, tank support, lower assembly	RF.3996	2	=
STRAP, tank support, upper assembly	RF.3994	2	=
STRAP, tank support assembly	RF.8833	2	*
TANK, fuel assembly (Flat type)	RF.8060	1	=
TANK, fuel assembly, ('R' Type)	RF.9232	1	*
TUBE, filler lower	RF.4257	1	=
TUBE, filler intermediate	RF.4258	1	=
WASHER, Aluminium 1.000" dia., tank drain plug	KB.1084	1	*
WASHER, C & A, 1.000" dia., tank, drain plug	KB.7620	1	=
WASHER, plain, 2 BA, tank guard	K.4404/Z	4	*
WASHER, plain, .250" dia., strap support bolt	K.4407/Z	6	=
WASHER, plain, .250" dia., strap support bolt	K.4407/Z	2	*
WASHER, retaining, fuel filler cap	RF.9210	1	
WASHER, sealing, fuel filler cap	RF.9209	1	
WASHER, spring, gauge, unit screw	K.9005/Z	6	
WASHER, spring, 2 BA, tank guard	K.9006/Z	4	*
WASHER, gauge unit	RF.8404	1	*

NOTE:- * Required when "R" Type fuel tank is fitted.

= Required when Flat Type fuel tank is fitted.